

Cut out this remote access card so that you can take it with you to help you use the remote features.

Déplacer  
l'auto  
\* Neige!

Le nom de ma voisine  
est Alexandra.

Write your 3-digit security code here:

3 3 3

1. Dial phone number of the answering system.
2. Enter 3-digit security code during greeting or after the beep.
3. Enter touch-tone command.
4. Hang up.

29875 Digital Answering System

To:	Press:
Play messages.....	1
Play previous..... <i>(during message playback)</i>	7
Skip to next message..... <i>(during message playback)</i>	9
Erase message..... <i>(during message playback)</i>	0
Turn on answering system.....	2
Turn off answering system.....	3
Record message..... <i>(press 6 again when finished)</i>	4
Record greeting..... <i>(press 6 again when finished)</i>	5
Stop playback..... <i>(during message playback)</i>	6
To set security code.....	7
Play greeting.....	8
Erase message.....	0

FOLD